

# ZooCADA<sup>®</sup> - Log

## **Enclosure Climate Monitoring Station**

ZooCADA-Log is a software program and hardware system designed to monitor and record the climate and soil conditions in animal enclosures at zoological facilities.

- ★ Automate the collection of enclosure climate data.
- ★ Automatically email staff when enclosure alarms occur.
- ★ Record enclosure data to support research and management.
- ★ Enable staff to focus more on animal care and conservation tasks.



# ZooCADA-Log Program Features

## Data Logging

- Enclosure and external temperature and RH values logged every 10 minutes.
- Enclosure and external max, min and average temperature and RH values logged daily.
- Enclosure soil moisture content and soil temperature logged every hour. (Optional)
- Enclosure min, max and average soil moisture content and soil temperature logged daily. (Optional)
- Auxiliary sensors can be installed with adjustable logging interval and daily avg/min/max logged. (Optional)
- Barometric pressure sensor with hourly logging. (Optional)
- Electricity use in kWh logged as hourly and daily totals. (Optional)
- Event log of last 1000 alarm and system control events.
- Datalogging memory in excess of 1 year between downloads before memory overwrite.
- Data logged to ring memory so oldest data is overwritten first when memory full.

## Alarms

- Power failure. (The electricity supply to the enclosure has failed)
- Communications failure. (The station can't obtain data from another station)
- External Sensor Failure. (For stations with external air temperature and RH sensors)
- Enclosure temperature too high.
- Enclosure temperature too low.
- Enclosure sensor failure.

## General

- Battery backup of datalogger 12V power so system keeps logging data during power failure.
- Alarms sent via email to staff if power fails, or if communications to a remote station fails.
- Communications to stations via LAN enables staff to monitor system operation.
- Communications to stations via LAN enables automated or manual collection of logged data.

ZooCADA-Log is a station of our modular control and data acquisition system. Each station can operate standalone or as an integral part of a fully networked, zoo-wide, system with various stations performing different tasks. Using our modular approach, numerous stations, distributed over a wide geographic area, can be networked provided that network connectivity (typically the site's IP computer network) is available at each station.

Adena Scientific believes that accuracy and reliability are paramount requirements of any system used in applications that support animal welfare, so we purpose designed our ZooCADA software to meet zoological needs, and built it to run on dataloggers manufactured by Campbell Scientific Inc.

The logo for Adena Scientific Ltd features the company name in a stylized, italicized yellow font. The letter 'A' is significantly larger and more decorative, with a blue dot above it and a blue line that curves around the top and left side of the 'A'.

**PO Box 756, Hamilton, New Zealand. Tel: (07) 829-7063 Email: [sales@adena.co.nz](mailto:sales@adena.co.nz)**